

NetTalk Phone Adaptor Installation Guide

1.	To download NetTalk Telephony Phone Adaptor Installation Program	2
	To open the NetTalk Telephony Service Welcome page	
	To select actions in Main page	
	To install the NetTalk Phone Adaptor	
4.1.	Step 1	3
4.2.	Step 2	
4.3.	Step 3	
4.4.	Step 4	
4.5.	Step 5	
4.6.	Step 6	
4.6.1	. PPPoE settings	6
4.6.2	DHCP Settings	6
	8. Fixed IP Settings	
4.7.	Step 7	8
4.8.	Exit the setup and plug in the phone set	8
4.9.	To install your Broadband/Wireless router	9
5.	To test your NetTalk Phone Adaptor	O

1. To download NetTalk Telephony Phone Adaptor Installation Program

- Please go to download area http://www.newworldtel.com/telephony/download/ and select the below installation program
 - NetTalk Telephony Phone Adaptor Installation Program (D-link DVG-5402SP version)



2. To open the NetTalk Telephony Service Welcome page

Double click the DIY icon to start

Choose the display language and click "Next" to continue
 Install Wizard V2.8
 新世界電訊
 Net*Talk

Welcome to NetTalk Telephony Service
 歡迎使用新世界電訊 NetTalk 電話服務

Choose the display language


Please select language

請選擇語言

Click "Next" to continue

Next Exit

You must configure your PC as DHCP in order to start the installation. Please click "Yes" to accept the program to change it automatically.



3. To select actions in Main page

- To install the NetTalk Phone Adaptor, click the "Install" button
- To test the NetTalk Phone Adaptor, click the "Diagnosis" button
- To read user manual, click "Read User Manual"
- To install Acrobat Reader, click "install Acrobat Reader"
- To seek technical support, click "Technical support"
- To go back to language selection, click the "Home" button
- To exit the setup programme, click the "Exit" button




4. To install the NetTalk Phone Adaptor

4.1. Step 1

To go to technical


support

Disconnect the LAN cable connecting to PC and leave the modem aside temporarily and then click "Next" to continue



4.2. Step 2

Connect the power cable to the NetTalk Phone Adaptor and then plug in the power adaptor to a power socket and then click "Next" to continue




4.3. Step 3

Connect a LAN cable to the LAN port of the NetTalk Phone Adaptor and the LAN port of your PC and then click "Next" to continue




4.4. Step 4

Reconnect the LAN cable from your modem to the WAN port of the NetTalk Phone Adaptor and then click "Next" to continue



4.5. Step 5


Select the connection method provided by your service provider and then click "Next" to continue



4.6. Step 6


4.6.1. PPPoE settings


Enter your PPPoE Login ID and Password and then click "Next" to continue



4.6.2. DHCP Settings


Wait until the settings has been saved and NetTalk Phone Adaptor to be activated and then click "Next" to continue






4.6.3. Fixed IP Settings

Enter your IP address information and then click "Next" to continue



4.7. Step 7

Wait for system check to be completed and then click "Next" to continue




4.8. Exit the setup and plug in the phone set

Click "Finish" to exit the setup programme and then connect your phone set to the Phone port 1 and start using our voice service.



4.9. To install your Broadband/Wireless router

If you have your own broadband or wireless router, please carry out the steps as instructed and then Click "Finish" to exit



5. To test your NetTalk Phone Adaptor



Wait for checking to be completed and then click "Finish" to exit

Install Wizard V2.8

Net*Talk

Diagnosis:

Connectivity Check

Internet Connection Check

NetTalk Phone Adaptor Check

NetTalk Phone Adaptor Check

System check is completed. Please click "Finish" to Exit or click "Retry" to check again

Retry

Finish

- END -